


## Program 1300 - Date and Time Programming

Use this program to set the clock and calendar on your *ER-5215M*. The date changes automatically. After initial setting, time changing will probably be required only for beginning and ending daylight savings time.

### ***Programming the Date and Time***

1. Turn the control lock to the **P** position.
2. To begin the program, enter **1 3 0 0**, press the **SBTL** key.



3. Enter time in military standard time (based on 24 hours), must be four digits (i.e. 1300 hours = 1:00 PM); press the **X/TIME** key.



4. Enter the date in MM(month) DD(day) and YY(year) format. Press the **X/TIME** key:



5. Press the **CASH** key to finalize the program.

